




VERY IMPORTANT!

Check which holes the spring is hooked up to, referring to Table "A" (if a single accessory is installed), or to Table "B" (if multiple accessories are installed). If the result does not conform, move the spring to the correct holes.



Tab. A	M3BAR		M5BAR			M7BAR	LBAR
	2,65 m XBA15 (3,15 m) - 0,50 m	3,15 m XBA15 (3,15 m)	3,50 m XBA14 (4,15 m) - 0,65 m	4,15 m XBA14 (4,15 m)	5,15 m XBA5 (5,15 m)	7,33 m XBA15 + XBA14	9,33 m XBA14 + XBA5
XBA13	A 1	A 3	B 2	B 3	C 2	B 2	B 1
XBA13 XBA4 / XBA6 / XBA18	A 1	A 3	B 2	B 3	C 2	B 2	B 1
XBA11	B 3	B 3	C 1	C 3			

Tab. B	M5BAR		M7BAR			LBAR	
	3,50 m XBA14 (4,15 m) - 0,65 m	4,15 m XBA14 (4,15 m)	5,15 m XBA5 (5,15 m)	5,00 m XBA15+XBA15 (6,30 m) - 1,30 m	6,33 m XBA15 + XBA15	7,33 m XBA15 + XBA14	8,33 m XBA14 + XBA14
XBA13	(0)	(0)	(0)	(0)	(0)	(0)	(0)
XBA13 XBA4 / XBA6 / XBA18	(1)	(1)	(1)	(1)	(1)	(1)	(1)
WA13	(1)	(1)	(2)	(1)	(1)	(2)	(2)
WA12	(5)	(4)	(4)	(3)	(3)	(3)	(3)
	0 ÷ 1 =	0 ÷ 1 =	0 ÷ 2 =	0 ÷ 2 =	0 ÷ 2 =	0 ÷ 2 =	0 ÷ 2 =
	B 2	B 3	A 2	B 1	B 1	A 1	A 3
	2 ÷ 7 =	2 ÷ 4 =	3 ÷ 5 =	3 ÷ 5 =	3 ÷ 5 =	3 ÷ 4 =	3 ÷ 6 =
	B 3	C 1	A 2	B 2	B 2	A 2	B 1
		5 ÷ 6 =	6 ÷ 7 =			5 ÷ 6 =	
		C 2	A 3			A 3	

1 - Add up the numbers in brackets in the column, choosing only those corresponding to the accessories installed.

2 - Use the sum of these numbers to identify the holes to which to anchor the spring.